






#### 1. ADDING THE TRU-AXIS ADAPTER

















## 2. IMPORTANT SAFETY FEATURE ADDING THE SLIDE STOP








CAUTION


The stop is necessary to keep the Tru-Axis Slide from sliding off the bottom of the tool holder when unlocked. Tighten firmly with supplied hex wrench.


Check the bolt periodically to make sure the stop is securely fastened.


LIT-461 Page 2 of 4

#### 3. BENCH ATTACHMENT & TOOL ATTACHMENT












#### 4. HEIGHT ADJUSTMENT





CAUTION


Place one hand to support the bottom of the Slide & Lock Tool and the weight of all attached tools before unlocking for height adjustment.















### 5. SWITCHING THE LOCK FOR LEFT-HANDED USE (OPTIONAL)









# GRS Slide & Lock Tru-Axis Adapter PARTS LIST • #004-753

