




Foot Control

for Rotary Air Handpiece #004-863

Connect the clean, dry, oil-free air supply hose to a filtered air regulator that is recommended by the rotary handpiece manufacturer.

If you own a GraverMax® G8, GraverMach®, GraverMax® SC, GraverMax®, GraverMate®, you may attach the air supply hose to the AUXILIARY AIR port located at the front of the machine. For connection on the GraverMach® AT, this connection is in the rear of the unit but the AUXILIARY AIR control is on the front panel. The GRS® Foot Control is virtually maintenance free... just clean occasionally.



1. CONNECT HOSE ON RIGHT SIDE TO AIR SUPPLY REFER TO ROTARY HANDPIECE REQUIREMENTS



2. CONNECT LEFT HOSE TO ROTARY HANDPIECE

IMPORTANT: Do not operate a rotary handpiece until you are thoroughly familiar with proper operating procedure. READ THE INSTRUCTIONS THAT COME WITH THE ROTARY HANDPIECE CAREFULLY.

GLEND0 LLC

900 Overlander Road • Emporia, KS 66801 USA
800-835-3519 • 620-343-1084 • Fax: 620-343-9640
grs@grstools.com • www.grstools.com
Last Updated: 2020-03-25

LIT-143