

2-Way Gravermeister HP Valve PART #001-507

5- Rubber Seal

INSTRUCTIONS

Installation


 Remove handpiece hose and outlet from valve body.

(Item 8, page 14 of manual)

2. Install valve, screwing it into valve body sufficient to compress rubber seal, hold the valve in position, and orient it as shown on sketch below.

3. Connect handpiece hoses to outlets on top and bottom.

4. Shift lever is located such that it indicates the operating outlet. (Top outlet is shown in "on" position in sketch).



900 Overlander Road P.O. Box 1153 Emporia, KS 66801 USA 800-835-3519 • 620-343-1084 fax 620-343-9640 glendo@glendo.com www.grstools.com