

SHELLAC TUBES


INSTRUCTIONS

Instructions apply to the following product(s):




502-506

FIG.1




There are 4 sizes of tube included with this set. Select the size best suited to your workpiece. Follow the shellac instructions to apply shellac and workpiece to cylinder.

FIG.2



A brass shellac tube is being inserted into a hole in a metal workpiece held in a lathe. A white arrow points from the tube to the hole.

FIG.3



A brass shellac tube is attached to a metal workpiece in a lathe. A curved arrow indicates the rotation of the workpiece.

Optional



Shellac tubes can also be attached by using the hole in the 3X Master Clamps.