



## **1. OVERVIEW**




## 2. SET UP


# ORIENTATION OF THE TOOL DIAL SEAT




# SELECTION AND INSTALLATION OF TOOL DIAL




## **GRAVER INSTALLATION**





## **FIXTURE POST**




# **3. SHARPENING WITH THE APEX DIAL**


## FACE (TOP OF THE GRAVER)

The face angle is the cutting angle of your graver. This will vary according to the hardness of the material to be cut.

#### 1 Grind

260 Grit ⇒ 600 Grit ⇒ 1200 Grit ⇒ Ceramic Sharpening Wheels






# V-ANGLE RESHAPING (BOTTOM OF THE GRAVER)

#### 2 Grinds

260 Grit ➡ 600 Grit ➡ (OPTIONAL) 1200 Grit Sharpening Wheels



# 3. SHARPENING WITH THE APEX DIAL (Continued)


# HEELS (BOTTOM OF THE GRAVER)

The heel is what allows you to control the depth of your cut much the same way a lever and fulcrum work.

#### 2 Grinds

#### 1200 Grit ➡ Ceramic Sharpening Wheels

Without power on the Power Hone, swipe the graver across the wheel to create the heel.



# 4. SHARPENING WITH THE DUAL ANGLE DIAL


## FACE (TOP OF THE GRAVER)

The face angle is the cutting angle of your graver. This will vary according to the hardness of the material to be cut.

#### 1 Grind

#### 260 Grit ⇒ 600 Grit ⇒ 1200 Grit ⇒ Ceramic Sharpening Wheels

Turn the tool dial to "F" and set the post angle to sharpen the face. Face angle is generally 45° - 55°. The steeper the face angle, the stronger your graver is. However, the steeper the face, the harder it is to see and place the point of your graver.



# V-ANGLE RESHAPING (BOTTOM OF THE GRAVER)


#### 2 Grinds


## 260 Grit $\Rightarrow$ 600 Grit $\Rightarrow$ (OPTIONAL) 1200 Grit Sharpening Wheels

GA, or graver angle is the angle of the graver such as a 90° or 120°.

A straight line is a  $180^{\circ}$  angle. Angles "A" + "A" + "GA" =  $180^{\circ}$  (FIG. 4.3). Using this formula and a little simple math, you can grind your own shaped gravers.

Set the post angle at 2.5°. Start with the tool dial set at 0 and rotate clockwise until angle "A" (see TABLE 4.1 or 4.2) is lined up with the tool dial register mark. Reshape the graver. Rotate the tool dial counterclockwise past 0 to the second angle "A" and reshape the second surface.





# 4. SHARPENING WITH THE DUAL ANGLE DIAL (continued)

# HEELS (BOTTOM OF THE GRAVER)

The heel is what allows you to control the depth of your cut, much the same way a lever and fulcrum work.

- Heel angle is generally 15° 20°
- The steeper the heel angle, the higher you must hold the back of the handpiece for proper cutting. Higher heel angles are great for cutting deep backgrounds that need a little extra clearance.

#### 2 Grinds

#### 1200 Grit ➡ Ceramic Sharpening Wheels

Without power on the Power Hone, swipe the graver across the wheel to create the heel.




TABLE 4.1 Graver with Traditional Heel								
GRAVER ANGLE								
"GA" Graver Angle / Shape	70	90	105	110	120			
FACE ANGLE SET TOOL DIAL TO "F"								
Post Dial Angle	45–55	45–55	45–55	45–55	45–55			
V-ANGLE RESHAPE SET POST DIAL TO 2.5°								
<b>Tool Dial Angle</b> <b>2 Grinds</b> Angle "A" (180 - GA) / 2 = A	55	45	37.5	35	30			
Heel Reshape Reshape	70° 70° 180° TOTAL	90° 180° TOTAL	105° (37.5° 180° TOTAL	110° / 35° 180° TOTAL	120° /30° 30°			
TRADITIONAL HEEL SET POST DIAL TO 15° – 20°								
Tool Dial Angle 2 Grinds • No power	55	45	37.5	35	30			

TABLE 4.2 Graver with Parallel Heel							
GRAVER ANGLE							
"GA" Graver Angle / Shape	70	90	105	110	120		
FACE ANGLE SET TOOL DIAL TO "F"							
Post Dial Angle	50	50	50	50	50		
V-ANGLE RESHAPE SET POST DIAL TO 2.5°							
<b>Tool Dial Angle</b> <b>2 Grinds</b> Angle "A" (180 - GA) / 2 = A	55	45	37.5	35	30		
Heel Reshape Reshape	70° 70° 180° TOTAL	90° / 45° 180° TOTAL	105° (37.5° 37.5°) 180° TOTAL	110° (35° 35°) 180° TOTAL	120° /30° TOTAL <sup>4</sup>		
PARALLEL HEEL SET POST DIAL TO 15°							
Tool Dial Angle 2 Grinds • No power	65.5	54	45.5	42.5	36.5		

# Apex Dual Angle Sharpening Fixture

PARTS LIST • #003-760, 003-761, 003-765, and 003-765-220

PART #	DESCRIPTION	QTY.	
Fixture			
002-759	0-RING, .625"0D .500"ID	1	
003-181	PLASTIC WASHER	4	003-435
003-182	0-RING	2	
003-217	LEG FOR DUAL ANGLE FIXTURE	1	
003-293	SLIDING PIVOT FOR DUAL ANGLE FIXTURE	1	
003-427	QC TOOL LOCK 1/4 TURN KNOB	1	
003-428	QC TEMPLATE SHARPENER ARM	1	
003-429	QC TOOL SHARPENER HEAD FOR TEMPLATE SHARPENER SYSTEM	1	
003-430	QC TEMPLATE FIXTURE ELEVATION DEGREE RING	1	
003-431	8-32 THUMB SCREW FOR SHAPRENING FIXTURES	2	
011-443	NYLON PILL	2	
022-188	6-32 X .500 SHCS BLK	2	
022-100	NYLON TIPPED SET SCREW FOR DEG DIAL	1	
		2	
	3/16 X .500 DOWEL PIN	1	
	I		
	nd Storage Rack	4	
	DUAL ANGLE TOOL DIAL	1	
003-432	90° APEX TOOL DIAL	1	
003-433		1	
003-434	120° APEX TOOL DIAL	1	
003-438	TEMPLATE WHEEL STORAGE RACK FOR QC TEMPLATE SHARPENER	{ 1	
	g Fixture Post		To watch Apex Sharpening
002-306	10-32 x .375 SHCS WITH NYLON PATCH	1	
003-426	MAGNET COVER TO REDUCE PULL	1	Fixture how-to videos, visit
003-436	EXTENDED LENGTH SHARPENING POST WITH PILOT DIAMETER	1	youtube.com/grstools. (( ⇔ ))
003-495	MAGNET COVER RETAINER TO HOLD ON I.D. OF MOLDED COVER	1	
022-363	POT MAGNET (CERAMIC)	1	
00 003-429 024-393 002-759			
GL	ENDO LLC 900 Overlander Road · E 800-835-3519 · 620-343- gr@grstools.com · www Last Updated: 2020-08-3 Made in USA / Printed in	1084 • Fax .grstools.c 1	x: 620-343-9640